

DrainStar® Wall Drain 200

Available from Tremco Barrier Solutions.

DrainStar®

PRODUCT DESCRIPTION

DrainStar® Wall Drain 200 is a two-part prefabricated soil sheet drain consisting of a formed polystyrene core covered with a non-woven, needle-punched polypropylene filter fabric on the dimpled side of the core. The fabric allows water to pass into the drain core, while restricting soil particles from entering. The core allows water to drain to designated drainage exits, such as weep holes, daylight exits, and sumps.

PACKAGING

4' x 50' rolls (200 ft²), 6 Rolls per Pallet (1200 ft²)

COLLECTION SYSTEMS

DrainStar Wall Drain 200 can be used with DrainStar strip drain, conventional pipe and stone systems, or "burrito wrap" systems for the collection and transportation of the water to designated exits.

ATTACHMENT METHOD

DrainStar Wall Drain 200 can be attached using nails (powder actuated, gas cartridge, or hand installed).



DrainStar Wall Drain 200 picture shows a two-part prefabricated soil sheet drain made up of polypropylene filter fabric (A) and polystyrene dimpled core (B).

INSTALLATION INSTRUCTIONS

Walls 4' or less

- 1 Cut DrainStar Wall Drain from bottom edge to desired height, ensuring that the bottom edge of the Wall Drain will rest directly above the weep holes, and the top flanged edge will terminate at desired finished grade.
- 2 Unwind roll of Wall Drain with the flange on top, and the bottom edge directly above the weep holes. Tuck the excess fabric at the top flanged edge behind the drain core and attach to the wall through the flange every 12 inches. Secure bottom of Wall Drain to the wall as needed to keep flush against wall.
- 3 Ensure all terminated roll ends are covered with fabric by removing 3 inches of the core and tucking fabric behind core. Fasten terminated edge to wall every 18 inches.

- 4 Install desired collection system (DrainStar Stripdrain, pipe and stone, or burrito wrap), ensuring that the weep holes and bottom edge of Wall Drain are covered by the collection system.

Walls greater than 4'

- 1 Unwind roll of Wall Drain with the flange on top, and the bottom edge directly above the weep holes.
- 2 Do not tuck the excess fabric at the flanged edge as described above.
- 3 Fasten to wall through top flange (core only) every 12 inches.

DrainStar®
Wall Drain 200

TREMCO
Barrier Solutions

800-876-5624 614-322-4420
6402 East Main Street
Reynoldsburg, OH 43068